Back checking is standard on flooring only, but is available on request for wall paneling & ceiling boards.

